

FITTING INSTRUCTIONS
MONTAGEANLEITUNG
INSTRUCTIONS DE MONTAGE
ISTRUZIONI DI MONTAGGIO
INSTRUCCIONES DE MONTAJE
ΟΔΗΓΙΕΣ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ

GB	Description Applications	SUNSHADES SX4 JY 2013-	Part Number Assembly Time	0078348ABC 0.15h
D	Beschreibung Verwendung	SONNENSCHUTZ SX4 JY 2013-	Teile Nr. Montagezeit	0078348ABC 0.15h
F	Designation Utilisation	PARE-SOLEIL SX4 JY 2013-	Numéro d'article Durée de montage	0078348ABC 0.15h
I	Descrizione Applicazioni	SOLE OMBREGGIA SX4 JY 2013-	Codice Art. Tempo di montaggio	0078348ABC 0.15h
ES	Descripción Aplicación	SOMBRILLAS SX4 JY 2013-	Referencia Tiempo de montaje	0078348ABC 0.15h
GR	Περιγραφή Χρήση	Ηλιοπροστασία SX4 JY 2013-	Μέρος Αριθμός Συνέλευση χρόνο	0078348ABC 0.15h

- CONTENTS**
- INHALT**
- CONTENU**
- CONTENUTO**
- CONTENIDO**
- ΠΕΡΙΕΧΟΜΕΝΑ**





