

INSTALLATION INSTRUCTIONS FOR PROTECTIVE AND GARNISH STRIPS

Note: Before installation of the moldings please read this manual carefully and proceed in the sequence presented below.

1. Before installation of the moldings ensure proper temperature conditions (20°C - 40°C) possibly identical for the car body and the mounted moldings.
2. Prepare thoroughly the surface of the body, where the moldings are to be fixed. For that purpose preferably clean thoroughly the surface with commonly available car cleaners, and then degrease it with extraction naphtha or similar safe chemical. (Due to use of evaporating agents pay attention not to inhale them and prevent the risk of fire – ventilation, working with the windows opened, or outdoors).
3. Leaving the self-adhesive protective foil (**3M**) on the moldings try putting them on the body and prepare for installation.
4. Next remove the color protective tape from the molding, trying not to touch the adhesive surface. Fix the moldings starting from the central post towards the bumper side.
5. Approximate assembling dimensions of the moldings are provided on the back (optionally).

Note: *Improper or twisted fixing of the moldings can result in wrong adherence to the body. The moldings should be glued to the body in one step, detaching them due to large adhesive force is not allowed. Next press them firmly against the body especially in the places with adhesive tape. The Manufacturer accepts no responsibility for any damage due to incorrect mounting.*

GUARANTEE CARD

Our products are covered by 24-month's warranty.

Please have this guarantee card stamped at the place of purchase showing the proof of purchase.

Date of purchase.....

.....
Seller's stamp

SUBARU IMPREZA 2011
.....

Car make



RIDER®



Subaru Impreza



TÜV Rheinland InterCert

